



UNIVERSITY OF CALIFORNIA - BERKELEY

DECLASSIFIED

TWO-WEEK LOAN COPY

*This is a Library Circulating Copy  
which may be borrowed for two weeks.  
For a personal retention copy, call  
Tech. Info. División, Ext. 5545*

RADIATION LABORATORY

## **DISCLAIMER**

This document was prepared as an account of work sponsored by the United States Government. While this document is believed to contain correct information, neither the United States Government nor any agency thereof, nor the Regents of the University of California, nor any of their employees, makes any warranty, express or implied, or assumes any legal responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by its trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof, or the Regents of the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof or the Regents of the University of California.



UNIVERSITY OF CALIFORNIA

Radiation Laboratory

Contract No. W-7405-eng-48

**DECLASSIFIED**

THE ABSORPTION SPECTRUM OF AMERICIUM

B. J. Stover, J. G. Conway, and B. B. Cunningham

August 3, 1950

**CAUTION**

This document contains information affecting the National Defense of the United States. Its transmission or the disclosure of its contents in any manner to an unauthorized person is prohibited and may result in severe criminal penalties under applicable Federal laws.

Berkeley, California

Standard Distribution: Series A

Copy Numbers

Argonne National Laboratory	1-10
Atomic Energy Commission, Washington	11-12
Brookhaven National Laboratory	13-16
Carbide & Carbon Chemicals Division (K-25 Plant)	17-18
Carbide & Carbon Chemicals Division (Y-12 Plant)	19
General Electric Company, Richland	20-25
Hanford Operations Office	26
Iowa State College	27
Kellex Corporation	28
Knolls Atomic Power Laboratory	29-32
Los Alamos	33-35
Mound Laboratory	36-38
Naval Radiological Defense Laboratory	39
NEPA Project	40
New York Operations Office	41-42
Oak Ridge National Laboratory	43-48
Patent Branch, Washington	49
Technical Information Division	50-64
UCLA Medical Research Laboratory (Warren)	65
University of California Radiation Laboratory	66-68
University of Rochester	69-70

Total 70

INFORMATION DIVISION  
Radiation Laboratory  
Univ. of California  
Berkeley, California

CONFIDENTIAL  
DECLASSIFIED

UCRL-854  
Chemistry-Transuranic Elements  
Page 3

THE ABSORPTION SPECTRUM OF AMERICIUM

B. J. Stover, J. G. Conway, and B. B. Cunningham  
Radiation Laboratory and Department of Chemistry  
University of California, Berkeley, California

Aug. 3, 1950

ABSTRACT

The absorption spectra of aqueous solutions and solid compounds of americium have been investigated with a Baird three meter grating spectrograph.

The relation of the spectrum to that of other actinide and rare earth compounds is discussed.

## THE ABSORPTION SPECTRUM OF AMERICIUM

B. J. Stover, J. G. Conway, and B. B. Cunningham  
Radiation Laboratory and Department of Chemistry  
University of California, Berkeley, California

## INTRODUCTION

It has long been observed that the absorption spectra of the trivalent rare earth ions possess a unique sharpness, the structure of the peaks being discernible at room temperature and even in solutions. This phenomenon has also been observed in the case of the electronically analogous actinide elements.

The generally accepted explanation for the origin of the lines in the rare earth spectra is that they result from transitions within the 4f electron shell.

Trivalent europium, the analog of americium, has been shown by absorption spectra and magnetic susceptibility data to have a  $4f^6$  electron configuration, a  $7F_0$  ground state, and one or more low lying excited levels. Since americium ion probably has a  $5f^6$  configuration, it also is expected to have a singlet ground state and one or more low lying excited levels. The following represents the first phases of the study of the absorption spectrum of americium.

## EXPERIMENTAL

A. Apparatus

A Baird Eagle Mount Spectrograph, having  $5.6 \text{ \AA}/\text{mm}$  dispersion in the first order, was used for both the solution and crystal work. For the solutions a 1 cm path length cell 2 mm wide was mounted on the arm of a micro-manipulator. The cell was then placed as close to the slit as possible. The cell was of fused silica. For the wave length below  $3500 \text{ \AA}$  a water cooled hydrogen discharge lamp was used, and above  $3500 \text{ \AA}$  a tungsten filament lamp.

Since the amount of americium available is not sufficient to permit the growing of large crystals, a projection system had to be used. Light from a

tungsten lamp was focused on the crystal and an image of the crystal focused on the slit of the spectrograph. The crystals were mounted in a cell made of 1/8-inch thick brass which had thin glass windows attached.

#### B. Solution Absorption Spectrum

The absorption spectrum of trivalent americium in perchloric acid solution has been measured in the wave length range 2200 to 10,000 Å, and the results appear in Table I. The spectrograms show a marked similarity to those of rare earth solutions, but the americium absorption is much more intense. The absorption in the 5000 Å region is especially strong and was found to persist at very low concentrations.

The measurements were made using a solution 0.04M in americium and 0.5M in perchloric acid. However, to detect the four components of the 5000 Å peak, it was necessary to reduce the americium concentration to about 10% of the above. With this solution none of the other lines were discernible.

#### C. Solid Absorption Spectrum

The absorption spectrum of samples of hydrated americium chloride containing approximately 100 micrograms of americium has been measured in the region 3500 to 5500 Å at room temperature, (Table II). Work is now in progress to extend this range and to obtain similar data at low temperatures.

The samples were prepared by slow evaporation of americium chloride solutions which had been carefully purified and which were approximately neutral.

The peak at 5000 Å was resolved into ten components, compared with the four found with the solution. To measure these ten accurately, it was necessary to photograph samples of several different thicknesses.

This work was performed under the auspices of the U. S. Atomic Energy Commission.

Table I

Am<sup>+++</sup> in HClO<sub>4</sub> at Room Temperature

$\lambda(\text{\AA})$	$\bar{\nu}(\text{cm}^{-1})$
8133	12,292
5166	19,353
5104	19,588
5078	19,686
5030	19,875
4543	22,003
4287	23,318
4198	23,815
4018	24,882
3784	26,420
3771	26,510
3756	26,617
3605	27,732
3391	29,477
3353	29,817
3312	30,189
2893	34,553
2861	34,940
2847	35,118
2826	35,380
2754	36,299
2705	36,952
2699	37,037
2651	37,715
2597	38,490
2537	39,406
2436	41,038
2433	41,096

Table II

Hydrated AmCl<sub>3</sub> at Room Temperature

$\lambda(\text{\AA})$	$\bar{\nu}(\text{cm}^{-1})$
5168	19,346
5163	19,364
5154	19,397
5139	19,454
5104	19,587
5084	19,664
5060	19,756
5047	19,808
4991	20,030
4974	20,098
4695	21,293
4646	21,517
4639	21,550
4596	21,752
4555	21,948
4429	22,572
4320	23,138
4314	23,170
3940	25,374
3800	26,307
3786	26,406
3761	26,578
3660	27,310
3621	27,602

CONFIDENTIAL

DECLASSIFIED

CONFIDENTIAL